


ELECTRIC RISING BARRIERS

BL227



TECHNICAL MANUAL

(Translation of the original French text)

Rev. 00

DOCUMENT REVISIONS

Revision	Date	Written	Checked	Purpose
00	01/09/2014	SLu	HBe/CDe/JJH	1st release.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

TABLE OF CONTENTS

1. OPERATING PRINCIPLE.....	5
2. FOOTPRINT / SOLUTIONS.....	6
3. LOCATION OF COMPONENTS	7
3.1. PARTS LIST	7
3.2. CONTROL BOARD.....	8
3.3. COMPENSATION ASSEMBLY	8
4. INSTALLATION	9
4.1. EQUIPMENT STORAGE BEFORE INSTALLATION.....	9
4.2. EQUIPMENT INSTALLATION	9
5. FIRST START-UP	ERREUR ! SIGNET NON DEFINI.
5.1. ROUND ARM Ø75 ASSEMBLY/DISASSEMBLY	11
5.2. HORIZONTAL/VERTICAL ADJUSTMENT.....	12
5.3. CHECKING / ADJUSTING THE COMPENSATION.....	15
5.4. ELECTRICAL CONNECTIONS	16
5.5. POWERING UP	17
6. CONTROL LOGIC PLA1300	18
6.2. ADDITIONAL PLA1301 BOARD (OPTIONAL)	22
6.3. THE HMI	24
7. ACCESSORIES / OPTIONS.....	28
7.1. DETECTION LOOPS	28
7.2. CONFIGURATION OF THE LOOP DETECTORS (OPTIONAL).....	30
7.3. ULTRASONIC DETECTOR REF. 4E5210 (OPTIONAL)	33
7.4. CONFIGURATION OF THE CARDIN RADIO TRANSMITTERS REF. 4E5445 (OPTIONAL).....	36
8. MAINTENANCE	37
9. TECHNICAL CHARACTERISTICS	38
10. MAINTENANCE AND TROUBLESHOOTING.....	39
10.1. PROBLEMS AND REMEDIES	39
10.2. ADJUSTING THE VARIABLE FREQUENCY DRIVE	41
10.3. OPENING THE TOP COVER	42
10.4. SWITCHING EQUIPMENT OFF	42
10.5. MANUAL RAISING OF ARM.....	43
10.6. REPLACING THE SPRING ASSEMBLY.....	43
10.7. TABLE OF MAIN SPRING ADJUSTMENTS	44
10.8. REPLACING THE POSITION SENSOR	46
10.9. REPLACING THE GEAR MOTOR	48
10.10. INVERTING THE SIDES FOR MOUNTING THE ARM	48
11. PROLONGED SHUTDOWN/DESTRUCTION	49
12. TERMINOLOGY	50
13. EC DECLARATION OF CONFORMITY	51
14. ANNEXES	52


Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

1. SAFETY WARNINGS

- This manual must be made available to any person working on the equipment: installers, maintenance technicians, end users, etc.
- This equipment has been designed to control and manage vehicle access and cannot be applied to any other use without risk to users or to the integrity of the equipment.
Automatic Systems cannot be held liable for damage resulting from improper use of the equipment.
- The contractor shall comply with local regulations when installing the equipment.
- The end of the arm must always be at least 0.5 m from any object.
- Pedestrian traffic must be prohibited within the area of operation of the barrier, unless its movement is effectively announced (sound and/or light signal, markings on the ground, etc.).

In the countries of the European Union, the EC Machines Directive stipulates that a sticker prohibiting pedestrian access must be placed on either side of the equipment (less than 1 metre upstream and downstream of the barrier's arm in horizontal position):



- The installation of detection loops (*optional*) must be validated by qualified personnel who will determine the loop arrangement best suited to the type of vehicle and passage configuration.

WARNING: There is a risk of injury if standard detection loops are used, as these may incorrectly detect trucks, bicycles or motorcycles and close the obstacle on these vehicles!

Note: For details, refer to the manuals on loops, available on <http://partnerweb.automatic-systems.com>

- Any work on the equipment must be performed by qualified personnel. Any unauthorized work or work performed by an unqualified technician on this product shall automatically void the manufacturer's warranty.
- The access keys to the mechanism must be used by personnel who are aware of the electrical and mechanical risks they incur in the event of negligent handling. These personnel are required to lock the mechanism's access hatch after the intervention.
- Assemble the arm and its accessories before performing any electrical tests (⇒see section 6.1.).
- **Lift the arm before performing any work inside** the housing to release the tension of the balancing springs and prevent undesired movements of the drive mechanism (⇒see section 11.5.).
- **As soon as the access door to the mechanism is open, cut power via the circuit breaker (⇒see section 11.4.).**
- **Never operate the barrier, even manually, without the adjustable stops (see section 4.1. , item 8).**
- Any internal component that may be live or that could move should be handled with caution.
- Do not add non-approved accessories (contact between different metals causes a battery effect that decreases the equipment's corrosion resistance).
- The equipment is configured to in "minimal risk" mode for users. Parameters should only be changed by qualified personnel with full knowledge of the consequences, and any changes to these parameters shall in no way entail any liability on the part of Automatic Systems.
- The obstacle must be completely visible to the potential user/operator before being put into operation.
- After a collision, even if there is no visible damage, the equipment must be carefully checked by a qualified technician.

2. OPERATING PRINCIPLE



Items referred to in this section can be seen on the images in section 4.

Arm opening (13) is controlled by a keyswitch, a push-button, a radio transmitter, a command sent over the network connection, detection loops buried in the roadway, or an external control device (tollbooth, card reader, management centre, etc.).

Closing is controlled in the same way, or automatically via a timer.

The processing of these commands may be made contingent on external information to be received by the barrier. For example, closing is not allowed if a vehicle is detected in the obstacle's path (information received from a detector), or opening is not allowed if the parking lot is full (information received via another device).

The movement initiated by the **gear motor** (4) is directly transmitted to the arm by the **main shaft Ø75** (5).



The speed of the arm, controlled by the **variable frequency drive** (72), is adjustable for both opening and closing movements. Movements are factory-configured to provide fast acceleration and slow deceleration at the end of the movement.

The **control logic** (3) coordinates the barrier's activity: management of movements and options, input and output information processing, etc. This information can be downloaded and processed by an external terminal (not provided by Automatic Systems).

A **compensating spring** (9) acts as a counterweight. It helps the motor during opening and closing based on accessories and lengths (models **without automatic raising** of the arm in case of power failure). For barrier models **with automatic raising** of the arm in case of power failure, the spring tension is increased to ensure that it can raise the arm by itself in the event of a power failure.

Maintaining the arm in its two extreme positions (open and closed) as well as after a Stop command is achieved by means of an **electromagnetic brake**: Normally Closed Brake (= closed when idle, i.e. not powered on), energized during arm movement to release the arm. For models with AVR (with automatic raising) (optional), the electromagnetic brake is of the NO type (= open when idle, i.e. not powered on), energized in the two end positions (open / closed) to ensure locking of the arm.

3. FOOTPRINT / SOLUTIONS




Note: Switching from one solution to another does not require additional parts.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

4. LOCATION OF COMPONENTS


4.1. Parts List



Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

4.2. Control Board



Item	Description
70	PCB steel plate
71	Electronics board
72	Frequency converter (+ filter)
73	Detector bracket
74	DIN rail
75	Terminal block

4.3. Compensation Assembly



Item	Description
9	Spring assembly ⁽¹⁾
80	Screw H M10x25 Zn ⁽²⁾
81	Hinge/spring
82	Nylon friction washer
83	Washer M 10 Zn

- (1) Includes spring and pre-assembled hinge
 (2) Installed with high strength thread lock

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

5. INSTALLATION

5.1. Equipment storage before installation

Before installation, protect equipment from impact and store it in its original packaging in a dry area protected from dust, heat and the weather.


Storage between -30 and +80°C.

5.2. Equipment installation

The barrier must be fastened to the ground, on a concrete base (Fig. b). The top of this base must be perfectly horizontal, and placed high enough to prevent any depression effect.

It is possible to embed the optional seal bracket, CHA0209, in this base (Fig. a). In this case, allow an excess threading length of 40mm for each bolt.

Seal bracket CHA0209 (optional)



Seal bracket assembly:

Insert the four anchoring bolts (1), each with a nut (2) and a flat washer (3), into the holes of the seal bracket (4). The thread must be oriented upward as shown on Fig. a. Attach the anchoring bolts to the seal bracket using the flat washers (3) and nuts (2), ensuring the anchoring bolts' threads protrude at least 40 mm. Fasten the nuts. Use adhesive tape on the threads protruding from the seal bracket to protect them from concrete splatter.

1. Install 2 sleeves with minimum 40 mm diameter to run the power and control cables (Fig. b). Install the required number of sleeves with 20 mm diameter to run the detection loop, blocking photocell and electrical tip support cables (optional). Cables must protrude 1 metre from the concrete base.
2. Make a concrete base in which the seal bracket will be centred as defined on Fig. b. The seal bracket must be flush with the surface of the concrete base and perfectly horizontal (Fig. b).
3. When the concrete has set, remove the adhesive tape from the threads, and remove the nuts and the flat washers in the upper part of the seal bracket. Install the sole plate on the concrete base using the previously removed washers and nuts.

Technical Manual BL227-MT-EN




Fig. b

Note:

If no seal bracket is available, it is possible to fix the barrier to the ground using 4 chemical anchors M12 minimum. A rubber sole (peplic joint) can be added between the concrete base and the barrier frame.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

6. COMMISSIONING


6.1. Round arm Ø75 assembly/disassembly

Notes: - All screws should be greased before assembly.

- Nominal tightening torques are given in the legend in the figure.

- The barrier must be open (⇒Ch.11.5.) before proceeding with arm assembly or disassembly.

1. Fit arm Ø75 (13) on the tube at the outlet of the main shaft Ø75 (5), and fasten with the stainless steel screws H M10x90 (13a), the stainless steel washers M10 (13b) and the stainless steel cap nuts M10 (13c).
2. Adjust the vertical and horizontal positions of the arm (⇒Ch.6.2.).
3. Adjust spring compensation (⇒Ch.6.3.).



To disassemble the arm, unscrew the stainless steel screws H M10x90 (13a) and remove the stainless steel washers M10 (13b) and stainless steel cap nuts M10 (13c).

Then slide the arm Ø75 (13) on the tube at the outlet of the main shaft Ø75 (5) upward so as to remove it.


Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.


6.2. Horizontal/Vertical Adjustment

6.2.1. Barrier model SR

- Turn off the barrier's power supply (⇒Ch.11.4.).
- Loosen the locknut (7.3).
- Screw or unscrew the lower stop (7.1) until the optimal horizontal position is obtained.



- Tighten the locknut again (7.3).
- Operate the manual brake release lever located on the motor (15, ⇒Ch.4.1.).
- Raise the arm into vertical position.
- Release the brake release lever.
- Loosen the locknut (7.3).
- Screw or unscrew the upper stop (7.2) until the optimal vertical position is obtained.




- Tighten the locknut again (7.3).
- Switch on the circuit breaker.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

6.2.2. Barrier model AVR

- Turn off the barrier's power supply (⇒ Ch. 11.4.).
- **Important:** Thanks to the spring(s), the arm is raised automatically.
- Loosen the locknut (7.3).
- Screw or unscrew the upper stop (7.2) until the optimal vertical position is obtained.



- Tighten the locknut again (7.3).
- Note down the position of the upper location of the spring on the hub (6) ⇒ Fig. 1.




Fig. 1




Fig. 2

- Loosen the locknut (9.1) and completely release the spring tension by loosening the nut (9.2) ⇒ Fig. 2.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

- Maintain the arm in vertical position and release the spring from the upper location on the hub by unscrewing the screw (80) ⇒ Fig. 3.





Fig. 3

- Lower the arm into horizontal position.
- Loosen the locknut (7.3).
- Screw or unscrew the lower stop (7.1) until the optimal horizontal position is obtained.



- Tighten the locknut again (7.3).
- Raise the spring and adjust its tension (⇒ Ch.6.3.).
- Switch on the circuit breaker.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

6.3. Checking / Adjusting the Compensation

For operation with automatic raising (optional) of the arm in case of power failure, the spring tension should be adjusted so that the arm is raised slowly and completely until it reaches its vertical position. The contact between the upper stop (7.2, Ch.6.2.) and the frame should not be too violent to avoid rapid deterioration.


If this is not the case, adjust the spring tension (see below).

For operation without automatic raising of the arm in case of power failure (SR models), the spring tension should be adjusted so that a minimal effort is required from the motor both for opening and closing the barrier:

- Enable the motor brake release lever (15, Ch.4.).
- Keeping the brake enabled, manually raise and then release the arm: it should remain in balance when positioned at 45°, and remain on its stops in the high and low positions.
If this is not the case, adjust the spring tension (see next page).
- Release the brake release lever.

Spring tension adjustment:

- Unscrew the nut (9.1).
- Tighten or loosen the nut (9.2) to tense or untighten the spring (9).



- If this adjustment proves insufficient, change the fixing hole of the spring (9) on the hub (6).
 - a) Bring the arm to its vertical position.
 - b) Turn off the equipment's power supply (⇒Ch.11.4.).
 - c) Decrease the spring tension (9) by loosening the nut a few turns (9.2).
 - d) Unscrew the screw (80) and change the position of the spring's on the hub (6) according to the table of the main spring adjustments (⇒Ch.11.7.).
- Adjust spring tension.
- Tighten the nuts and locknuts (9.2 & 9.1) and the fastening screw of the spring (80) on the hub (6).

Technical Manual BL227-MT-EN

6.4. Electrical connections



THE ARM MUST BE ASSEMBLED BEFORE PROCEEDING WITH ANY TESTS.




WARNING: Do not connect to a floating network or to a high impedance earthed industrial distribution network (high leakage currents).



WARNING: Work must be done in accordance with the safety warnings (⇒Ch.0)



Connections must be done **in accordance with the wiring diagrams** included **inside the equipment**, as these represent the primary reference instructions (this section is for information purposes only).



WARNING: Raise the arm (⇒Ch.11.5.) before making any electrical connections!

- Remove the top cover (⇒Ch.11.3.).
- Switch the circuit breaker OFF (⇒Ch.11.4.).
- Connect the power supply cables to the terminal blocks (14.2), ensuring that the power supply's characteristics meet the required specifications (⇒Ch.10.).
- The terminal block (14.1) must be grounded via a cable with a cross section of **at least 1 mm² or more depending on the applicable legislation**. (high leakage current: above 3.5 mA, but below 5% of the rated current)
- The following must be provided at the feeder head:
 - A 10 A/30 mA super-immune selective differential circuit breaker (for 1 barrier maximum)
 - A 10 A/300 mA differential circuit breaker (for 5 barriers maximum)
- Connect the various control elements and options in accordance with the diagrams supplied, leaving a space of 15 cm with the power cable reaching the terminal blocks (14.2).

Technical Manual BL227-MT-EN

6.5. Powering Up

1. Set the circuit breaker (14) to ON ⇒ the barrier's control program, stored in the control board PLA1300, takes about 10 seconds to start up and become operational.


Start-up progress is displayed on the HMI LEDs. They light up for 5 seconds to indicate that the program is installed and effective. After these 5 seconds, only the OK LED is lit (or blinks), according to the barrier's operating mode.

By default, the barrier is in automatic mode and the (green) OK LED is steadily lit.


During the start-up phase, the arm does not move. When this phase is completed, it is positioned as defined in the maintenance interface (see appropriate manual).

2. Once the software is operational, the HMI of the PLA1300 board can be used to issue open/close commands via the push-button. (Refer to the Logic manual)

If the movement is made in the opposite direction, swap the connection of 2 phase cables between the motor and the variable speed controller after having shut off the power supply (= swap the T1/U and T3/W cables in the figure below):



7. CONTROL LOGIC PLA1300



Item	Name
1	Connector XB1 (Reserved for control of the VSC and for the position sensors)
2	Connector XB2 (Terminals 0V, 12V and inputs I3 to I12)
3	Connector XB3 (terminals 0V, 12V and + for outputs O5, O6 and O7)
4	Connector XB4 (NO and NC contacts for outputs O3 and O4)
5	XRJ45 Ethernet link connector (for connection to a network or to a PC)
6	Serial link connector XSUPP (for programming the board or for connection of a PLA1301 extension board)
7	Connector XD3 (RS485 connector for control of a VSC)
8	Connector XD2 (Reserved for special use by Automatic Systems)
9	Connector B1B2 (Connector for single (1 loop) or double (2 loops) presence detector)


Item	Name
10	Connector XD1 (Connection of detection loop(s))
11	Label (serial number and software release)
12	Connector XG1 (Single-phase mains supply 230 VAC, 50/60 Hz + PE)
13	DIP switches
14	Push-button
15	Timer T1 adjustment potentiometer
16	Timer T2 adjustment potentiometer
17	I/O, Loop and HMI status display LEDs
18	Board model and version

Technical Manual BL227-MT-EN


The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

7.1.1. Characteristics of connector terminals

7.1.1.1. Connector XG1




7.1.1.2. Connector XB1 ¹



+	=	Potential-free terminal ²
O	=	Open command (⇒ VF)
F	=	Close command (⇒ VF)
PV	=	low speed command (⇒ VF)
-	=	Transistor ground
CAP ³	=	24 VDC power supply of the position sensors
I0	=	Digital input 0
I1	=	Digital input 1
0V	=	0 VDC
AI2	=	0 – 10V analog input ⁴

7.1.1.3. Connector XB2 ⁵



24 VDC sink/source inputs

24V	=	+24 VDC
24V	=	+24 VDC
I3	=	Digital input 3
I4	=	Digital input 4
I5	=	Digital input 5
I6	=	Digital input 6
24V	=	+24 VDC
24V	=	+24 VDC
I7	=	Digital input 7
I8	=	Digital input 8
I9	=	Digital input 9
I10	=	Digital input 10
I11	=	Digital input 11
I12	=	Digital input 12
0V	=	0 VDC
0V	=	0 VDC

¹ Connector reserved for digital control of a VSC ⇒ **For example**, see diagram Type **C220**, Ch.10 of the Technical Manual of PLA1300.

² Reserved for transistor outputs to be powered by the 24 VDC of the board or by the 24 VDC of another power source.

³ Or 5V depending on the shunt **ALIM CAP**.


⁴ This input can also be used as a 24 VDC digital input.

⁵ Inputs I7 to I12 operate both in PNP and in NPN. This means they can be used with either 24VDC or 12VDC, or 0V of the board (or of an external power source if the 0V are shared).

NB: That is why two 0V terminals are present on this connector.

Technical Manual BL227-MT-EN


7.1.1.4. Connector XB3



**Sink/source outputs
24 VDC**

- 24V = +24 VDC
- 24V = +24 VDC
- + = Transistor polarity
- O5⁶ = Transistor output limited to 150 mA
- O6⁶ = Transistor output limited to 150 mA
- 0V = 0 V or transistor ground
- 24V = +24 VDC
- + = Transistor polarity
- O7⁶ = Transistor output limited to 2.5 A
- 0V = 0 V or transistor ground


7.1.1.5. Connector XB4



**Dry contact outputs
(limited to 3A at 230V)**

- C3 = } relay output with changeover contact 230V 3A
- NO3 = }
- NC3 = }
- C4 = } relay output with changeover contact 230V 3A
- NO4 = }
- NC4 = }

7.1.1.6. Connector B1B2



- 1 = 0VDC
- 2 = +24VDC terminal block (max 0.75A)
- 3 = loop 1 (from XD1)
- 4 = loop 1 (from XD1)
- 5 = loop 2 (from XD1)
- 6 = loop 2 (from XD1)
- 7 = } Contacts of loop relay 1.
- 8 = } Contacts of loop relay 1.
- 9 = -----
- 10 = } Contacts of loop relay 2.
- 11 = } Contacts of loop relay 2.




Pin assignment specific to Automatic Systems.

⁶ This output can be powered by an external power source (hence the + and - terminals).

Technical Manual BL227-MT-EN

7.1.2. Connector XD1



B1 = } Terminal for connection of detection loop 1
B1 = }
B2 = } Terminal for connection of detection loop 2
B2 = }



If **only one loop** is connected, **a single presence detector has to be used**.
The use of a double presence detector could result in malfunctions.



A double presence detector is necessary if a second loop is connected.

7.1.3. DIP switches

The eight DIP switches (or microswitches) integrated in the PLA1300 programmable control board include, in relation to the active program, a series of functions allowing to rapidly modify the behaviour of the control logic.



Prior to any modification of the DIP switch, it is important to refer to the diagrams supplied with the equipment.

See the wiring diagram(s) supplied with the equipment.



Since priority is given to the web pages, it could be that, depending on the arrangement of the assignments on these pages, changing the position of a DIP switch does not actually modify the behaviour of the device.

7.1.4. Adjustment of hardware timers (potentiometers)

The two potentiometers present on the PLA1300 control logic can be used to adjust the following timers:

	MAX values	DEFAULT values	
T1	60 seconds	30 seconds	Timer for reclosing in case of non-passage
T2	10 seconds	2 seconds	Timer for reclosing after passage



- Turn the potentiometer clockwise to increase the timer value.
- Turn the potentiometer anticlockwise to decrease the timer value.




It is also possible to adjust other timers via the http maintenance interface.



- The assignment of the timers depends on the active program.
- The MAX values of T1 and T2 can be modified via the web pages.

Technical Manual BL227-MT-EN


7.2. Additional PLA1301 board (optional)



Item :	Name
1	Connector YB1 (2 24V terminals and 8 inputs: I13 ⇒ I20)
2	Connector YB2 (8 outputs: NO8 ⇒ NO15)
3	BR1225 battery (CR1225)
4	Connector YD2 (Reserved for special use by Automatic Systems)
5	Connector B3B4 (Connector for single (1 loop) or double (2 loops) presence detector)
6	Connector YD1 (Connection of detection loop(s))
7	Input/output display LEDs
8	Label (board serial number and software release)

7.2.1. Characteristics of connector terminals

7.2.1.1. Connector YB1




**Sink/source inputs
24 VDC**

24V	=	+24 VDC
I13	=	Digital input 13
I14	=	Digital input 14
I15	=	Digital input 15
I16	=	Digital input 16
24V	=	+24 VDC
I17	=	Digital input 17
I18	=	Digital input 18
I19	=	Digital input 19
I20	=	Digital input 20

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.


7.2.1.2. Connector YB2



Dry contact outputs
(limited to 3A at 230V)

C8	=	Common output 8
NO8	=	NO output 8
C9	=	Common output 9
NO9	=	NO output 9
C10	=	Common output 10
NO10	=	NO output 10
C11	=	Common output 11
NO11	=	NO output 11
C12	=	Common output 12
NO12	=	NO output 12
C13	=	Common output 13
NO13	=	NO output 13
C14	=	Common output 14
NO14	=	NO output 14
C15	=	Common output 15
NO15	=	NO output 15

7.2.1.3. Connector B3B4




1	=	0VDC
2	=	+24VDC terminal block (max 0.75A)
3	=	loop 1 (from YD1)
4	=	loop 1 (from YD1)
5	=	loop 2 (from YD1)
6	=	loop 2 (from YD1)
7	=	} Contacts of loop relay 1.
8	=	
9	=	----
10	=	} Contacts of loop relay 2.
11	=	



Pin assignment specific to Automatic Systems.

7.2.2. Connector YD1



B3	=	Terminal for connection of detection loop 3
B3	=	Terminal for connection of detection loop 3
B4	=	Terminal for connection of detection loop 4
B4	=	Terminal for connection of detection loop 4



If **only one loop** is connected, **a single presence detector has to be used**.
The use of a double presence detector could result in malfunctions.



A double presence detector is necessary if a second loop is connected.

Technical Manual BL227-MT-EN

7.3.3. The modes














The **9 accessible modes** are:

- **Mode 0:** to open/close the barrier or to initialize the analog sensor;
- **Mode 1:** to modify the timers;
- **Mode 2:** to modify the loop assignments;
- **Mode 3:** to modify the predefined functions;
- **Mode 4:** to modify the Output assignments;
- **Mode 5:** to modify the Input assignments;
- **Mode 6:** to modify the PLA1300 board programs;
- **Mode 7:** to modify the VFD programs and the Opening and Closing %;
- **Mode 8:** to modify direct actions such as:
 - 1: selection of type of VFD (0 = Digital / 1 = Serial)
 - 2: calibration (0 = no / 1 = yes)
 - 3: Sensor type (0 = Digital / 1 = Analog)
 - 4: Temporary reset of the IP address
 - 5: Factory reset of the IP address
 - 6: Reclosing upon detection of an obstacle (0 = no / 1 = yes)


7.3.4. OK LED display logic

The status of the **OK** LED during navigation in the HMI provides an excellent means of reference to the programming step being performed.



The following table presents the 5 possible statuses of the **OK** LED:

PLA1300: LED status OK				
	On			Auto mode
	Off			HMI: Choice of mode in progress
	50 %			HMI: Choice of parameter in progress or MANUAL
	20 %			HMI: Choice of value 1 of parameter in progress
	80 %			HMI: Choice of value 2 of parameter in progress
	Rapid blinking			HMI: Initialization of analog sensor in progress

7.3.5. Mode 0 – Opening/Closing or analog sensor initialization




To access the mode:

- Switch off the power supply of the board;
- Press and hold down the **PB** and restart the board;
- All LEDs of the HMI light up. Release the **PB**. (do not hold down for more than 3 seconds);
- The **OK** LED goes out .
- Repeatedly press the **PB** until LED **I7** is lit.
- To validate, press the **PB** until all LEDs of the HMI are lit. (approx. 3 seconds);
- The **OK** LED blinks .


Possible actions:

In this mode, the **PB** pressing time is very important.



Once this mode is selected, a:

- a **brief** button press will issue a barrier **open or close command** (*Remote switch mode / command to a contact*).
- a **long** button press (for more than 3 seconds) will launch the **initialization of the analog sensor** (the **OK** LED blinks rapidly ) , provided it has been declared.

7.3.6. Mode 6 - Modification of board programs



To access the mode:

- Switch off the board's power supply.
- Press and hold down the **PB** and restart the board.
- All LEDs of the HMI light up. Release the **PB**. (do not hold down for more than 3 seconds);
- The **OK** LED goes out .
- Repeatedly press the **PB** until LEDs **I7 and I8** are lit.
- To validate, press the **PB** until all LEDs of the HMI are lit. (approx. 3 seconds)
- The **OK** LED blinks .

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

To change the program:




Up to 29 VFD programs may be available in the PLA1300 board.

However, only the programs that are actually present in the board's memory will be available.

HMI display (LEDs)	Program N°	HMI display (LEDs)	Program N°
I8-O6	Program 1	I7-I8-O7	Program 16
I9-O6	Program 2	I7-I9-O7	Program 17
I10-O6	Program 3	I7-I10-O7	Program 18
I11-O6	Program 4	I7-I11-O7	Program 19
I12-O6	Program 5	O6-O7-I7	Program 20
I8-O6-I7	Program 6	O6-O7-I8	Program 21
I9-O6-I7	Program 7	O6-O7-I9	Program 22
I10-O6-I7	Program 8	O6-O7-I10	Program 23
I11-O6-O7	Program 9	O6-O7-I11	Program 24
I7-O7	Program 10	O6-O7-I12	Program 25
I8-O7	Program 11	O6-O7-I7-I8	Program 26
I9-O7	Program 12	O6-O7-I7-I9	Program 27
I10-O7	Program 13	O6-O7-I7-I10	Program 28
I11-O7	Program 14	O6-O7-I7-I11	Program 29
I12-O7	Program 15		



If you try to validate a program that does not exist, the validation will not be executed and you will remain in the program choice mode (the **OK** LED will continue to blink  until a valid program is chosen).

When the program of the PLA1300 board is chosen and validated, the board will be reinitialized and the previously chosen program will become active.



The modification of this program must be performed by an informed, qualified technician, because the configuration of inputs, outputs, loops, etc. may be different and may thoroughly alter the behaviour of the PLA1300 board and therefore also that of the connected equipment.



For details on the configuration of the PLA1300 control logic, refer to the appropriate technical manual.

8. ACCESSORIES / OPTIONS


The barrier can be equipped with one or more options.

Consult our sales representative to check the feasibility and availability of the chosen options.

8.1. Detection loops

Implementation and installation of magnetic loop(s)

Barrier systems with automatic closing generally use inductive loops to detect the passage of vehicles. These loops can be purchased ready to be installed. You can, however, also manufacture your own loops by observing the following instructions:



- Use individual wire with a cross section of 1.5 to 2.5 mm², type H07 VK



* Observe the number of turns.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.


Notes:

- Twist the wires to form the loop tail, taking at least 10 twists per metre as a minimum, so as to cancel the detection effect on the loop tail. The loop tail may not be longer than 50 m, and must be protected by a sleeve Ø 20mm used exclusively for this purpose.
- Check that the loop inductance falls between 60 and 180 μH .
- The loop must be at least 2 metres away from all power supply cables.
- The loop must be at least 1 metres away from any moving metal object.
- If the loop is positioned in reinforced concrete, it must be more than 100 mm away from the frame.
- Manhole covers, sewer pipes, water intakes, etc. must be installed more than one metre away from the loop (so as not to reduce the efficiency of the loop).
- The underlying ground, and the covering, must be sufficiently dense to prevent the loop from moving during the passage of vehicles.
- When installing the loop, make sure that it cannot move afterwards (when closing the opening or installing the pavers). Any movement of the loop is interpreted as an inductance variation and may cause unwanted openings of the barrier or blocking in the open position of the barrier.
- Do not install the loop in a sleeve.



For the passage of heavy weights, install 2 safety loops or 1 longer loop.

Configuration example:



Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

8.2. Configuration of the Loop Detectors (Optional)


The presence detectors associated with the inductive loops may be one of the following two models:

- ❗ The detectors must be installed and removed carefully so as not to alter, or even destroy, the PLA1300 board.
- ❗ Because of the specific cabling for the electronic boards delivered with Automatic Systems barriers, standard commercially available detectors cannot be used. For particular settings or in case of failure, please contact our Customer Service.

The presence detectors associated with the inductive loops may be one of the following two models:

8.2.1. Type 1 Detectors

The range of type 1 detectors is a series of single- or double-channel inductive loop detectors:




1: Power supply pilot light

Green when the module is powered on.


2: Potentiometer used to set the presence detection time

= After which time, on a presence detection, the detector reinitializes (i.e., takes the value measured by the loops as reference level).
The default setting is **Infinite** (turned fully clockwise), which prevents the detector from reinitializing.



3: Potentiometer used to set the sensitivity of loop A (for double detectors).

Setting to be adjusted on site according to environment and loop sensitivity: increase loop detection sensitivity by turning the potentiometer clockwise or decrease the presence detection time (see point 2)



4: Activation pilot light of loop A (for double detectors).

Upon power-on: blinking red. The number of blinks indicates the number of tens of kHz of the loop

Technical Manual BL227-MT-EN

oscillating frequency.

Error message, based on blinking frequency:

- 1 blink per second: loop frequency too low or loop open. Adjust with DIP switches 1 and 2 or modify the number of turns of the loop.
- 2 blinks per second: loop frequency too high Adjust with DIP switches 1 and 2 or modify the number of turns of the loop.
- 1 blink every 2 seconds: loop short-circuited. Check cables.

Normal operation: LED not lit, then continuously red during presence detection in the loop.

5: Potentiometer used to set the sensitivity of a single loop (for single detectors) or loop B (for double detectors).

Same operation as described in 3.

6: Activation pilot light of a single loop (for single detectors) or of loop B (for double detectors).

Same operation as described in 4.

7: DIP switches.

Default setting (DIP switch is OFF when it is pointing to the number side of the DIP, i.e., on the left when looking at the detector from the front as illustrated below):



Every time a modification is made to a DIP switch, the detector reinitializes (see point 2).

DIP switches 1 and 2: Loop frequency setting:

DIP 1	DIP 2
OFF	OFF
ON	OFF
OFF	ON
ON	ON

Single detector
Single loop
High
Mid-high
Mid-low
Low

Double detector	
Loop A	Loop B
High	High
Low	High
High	Low
Low	Low

DIP switch 3: Relay configuration: active or passive.

DIP switch 4: Automatic Sensitivity Boost. To detect metal vehicles with various heights (trucks, 4x4s, etc.) with greater precision, the DIP switch should be set to ON.

May cause malfunctions and is therefore to be used as a last resort.

The default setting is OFF to increase sensitivity to tailgating fraud (detection of two vehicles close to each other).

Technical Manual BL227-MT-EN

DIP switch 5: Operating mode of relay A (presence or pulse).

DIP switch 6: Pulse type of relay A (input or output) or mode of relay B (non-directional or directional A → B).

DIP switch 7: Operating mode of relay B (presence or pulse) or choice of loop (A or B) for pulse.

DIP switch 8: Pulse type of relay B (input or output).

DIP switch 9: To set the pulse duration of both relays (100 ms or 500 ms).

DIP switch 10: Double loop mode (independent of the A→B combination).



Because of the specific cabling for the electronic boards delivered with Automatic Systems barriers, standard commercially available detectors cannot be used. For particular settings or in case of failure, please contact our Customer Service.

8.2.2. Type 2 Detectors


Detector DP134 ref. 4E4623 or 0/7104/179 (1 loop)

PRES: Always to be set to ON.

PULSE: Always to be set to OFF.

FILTRE: Always to be set to OFF.


ASB: Sensitivity booster to be used for high vehicles. This function should preferably remain OFF.



SENS: Detection sensitivity adjustment.
See principle below.

FREQ: Frequency of use adjustment.
See principle below.

There are four sensitivity and frequency settings:



ON

High



ON

Mid-high



ON

Mid-low



ON

Low



PRESS "RAZ" AFTER MAKING A MODIFICATION - DURING INITIALIZATION, MAKE SURE NO METAL OBJECT IS PRESENT ON OR IN THE PROXIMITY OF THE LOOP

Technical Manual BL227-MT-EN

Detector DP234 ref. 4E4624 or 0/7104/180 (2 loops)

PRES: always to be set to ON.

ASB: Sensitivity booster to be used for high vehicles. This function should preferably remain OFF.

SENS 1: Detection sensitivity adjustment of loop 1. See principle below.



SENS 2: SENS 1 : Detection sensitivity adjustment of loop 2. See principle below.

FREQ: Frequency of use adjustment of both loops. See principle below.

There are four sensitivity and frequency settings:



ON

High



ON

Medium high



ON

Medium low



ON

Low




PRESS "RAZ" AFTER MAKING A MODIFICATION.

8.3. Ultrasonic Detector ref. 4E5210 (optional)

8.3.1. Description

The ultrasonic detector detects any object located within its detection area. This cone-shaped area has a configurable length from 350 to 5000 mm. All adjustments are made by means of two keys and a digital display. Bi-colour LEDs, orange/green, indicate the switching status of the output, which can be configured as normally open (NO) or normally closed (NC).

8.3.2. Mechanical characteristics




Technical Manual BL227-MT-EN


8.3.3. Detection

Dead zone: 350mm
Service range: 3400mm
Limited range: 5000mm

The ultrasonic sensor has a dead zone that is inherent in its detection technology. Detection of an object in this zone is not significant.
The service range corresponds to the distance at which the sensor can be used on normally reflecting objects with a sufficient operating reserve.
This view shows the effective detection volume of the sensor as a function of the distance. The red area is the zone in which a cylindrical bar Ø27mm is detected, and the blue area the zone in which a square plate with 500mm sides, positioned at an optimal angle, is detected.



8.3.4. Electrical connections



8.3.5. Configuration

Any sensor delivered with a barrier is mounted, pre-wired and adjusted according to the following parameters:


- Output contact: NC (normally closed)
- Detection range: useful length of the arm associated with the barrier

For the configuration of a separately supplied sensor (after-sale service, later addition), the output contact parameters and the detection range should be checked and/or adjusted by performing the following steps:

1. **Press T1+T2** for approx. 3 seconds until **Hello** followed by **Pro** is displayed.
2. **Release T1+T2**, the display indicates **d**
3. **Press T1+T2** to go to the switching distance setting
Set the switching distance in relation to the useful length of the arm by pressing **T1** (to decrease the value) or **T2** (to increase the value).
4. **Press T1+T2**
5. **Press T2** until the display indicates "- - -" (single mode)
6. **Press T1+T2** to go to the NO (\neg | \neg) or NF (\neg |) setting
T1 or **T2** changes the direction
7. **Press T1+T2** until **END** is displayed
8. **Press T1+T2** to return to the **operational mode**

8.3.5.1. Synchronization

If several sensors are to be installed in the same area, and if the distances between the sensors are less than those given in the figure here, the sound signal of the sensors may be severely disturbed. In these cases, a simple solution can be implemented by modifying the value of the A12 parameter in the additional functions. For this, the following principle should be followed:



- **Adjustment A** corresponds to value **670** for parameter **A12**
- **Adjustment B** corresponds to value **770**
- **Adjustment C** corresponds to value **840**
- **Adjustment D** corresponds to value **910**
- **Adjustment E** corresponds to value **980**
- **Adjustment F** corresponds to value **999**

Parameter A12 is modified as follows:

1. **Press T1+T2** for approx. 7 seconds until **Add-On**, followed by **A1** is displayed
2. **Press T1 or T2** until **A12** is displayed
3. **Press T1+T2** to validate
4. **Press T1 or T2** to modify the indicated value
5. **Press T1+T2** to validate. **End** is then displayed
6. **Press T1+T2** to return to the operational mode

8.3.5.2. Note

Ultrasonic sensors have an internal temperature compensation. The sensor has a normal temperature rise on the inside, so that the compensation becomes optimal after approx. 30 minutes of operation. During normal operation, the yellow LED D2 indicates the switching of the output, and the measured distance is indicated on the 3-digit display in millimetres (up to 999 mm) and then in centimetres. The scale changes automatically and is indicated by a point at the top right of the display. If no object is located within the detection area, the display indicates "- - -".

If no button is operated for 20 seconds during the parameter adjustment phase, the changes made are stored and the sensor returns to normal operating mode.

Technical Manual BL227-MT-EN

8.3.5.3. Maintenance

Ultrasonic sensors do not require any particular maintenance. Small quantities of dirt or dust on the surface will not affect their characteristics. In the event of excessive deposits on the sensitive surface, clean it with a damp cloth to preserve the detection reliability.

8.4. Configuration of the CARDIN radio transmitters ref. 4E5445 (optional)



Activation of the transmitters

1. Open the cover of the radio transmitter. Press and hold down button P1 "Memo". LED L1 starts to blink slowly.
2. Simultaneously press the key of the transmitter to be programmed. LED 1 stops blinking for a few seconds.
3. When the LED starts to blink again, release button P1.
4. Validate the programming by again pressing the key of the transmitter to be programmed.

Deactivation of the transmitters

1. Press button P2 "Delete". L1 blinks rapidly.
2. Simultaneously press the button to the left of the transmitter. The LED remains lit for 2 seconds, indicating that the transmitter is deactivated.



The key to the left of the receiver corresponds to the receiver's CH1 contact, the key to the right of the receiver to the receiver's CH2 contact.

9. MAINTENANCE



ALL MAINTENANCE OR SERVICING MUST BE PERFORMED WITH THE POWER SWITCHED OFF AND IN ACCORDANCE WITH THE SAFETY WARNINGS (⇒ Ch.0).

Every year^(*)

- Ensure internal screws and bolts are properly tightened (torque): bearings, gear motor, hub, sensors, spring assembly, arm attachment, base attachment, etc.
- Clean the body and the arm with a soft cloth impregnated with a non-aggressive detergent.
- For very sunny countries, it is advisable to treat the exterior of the body with a glossing product.
- Shut off the electrical power supply and check the behaviour of the arm:
 - o For models with automatic raising, the arm should rise completely but without violently hitting the end stop.
 - o For models without automatic raising, the arm should be able to rise manually with more or less effort.
- Blow out the electronic board + frequency converter assembly so as to remove any deposits of exhaust particles.

Every 2 years^(*)

- Ensure screws and bolts are properly tightened (torque): bearings, gear motor, hub, sensors, spring assembly, arm attachment, base attachment, etc.
- Check the state of the electrical connections.
- Check the sole plate for absence of leaks.
- Check the inside of the barrier for cleanliness.

^() To be adapted according to equipment operating conditions, especially when the equipment is located in an oxidizing climate (e.g., near the ocean).*

10. TECHNICAL CHARACTERISTICS

Electrical power supply	Single-phase 230 V~ (± 10%) + ground – 50 Hz
Useful power consumption	450 W while moving (44W at rest)
Motor	Three-phase 230 V/250 W
Free passage [L]	2 to 6 m, in increments of 0.5 m
Operating time:	Adjustable between 1.5 and 3.5 seconds (Capacity for controlling congested periods: 8 to 15 vehicles/minute)
Operating temperature:	Between –20° and +60°C.
Average relative humidity	95%, without condensation
IP	IP44
Sound level	< 70db
Weight	Net weight (excluding arm): 80 kg Arm: 15 kg max.
MCBF	2,500,000 mean cycles between failures, with recommended maintenance.
CE	Complies with European standards

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

11. MAINTENANCE AND TROUBLESHOOTING



Prior to any work on the inside of the housing, the arm must be in the high (open) position (⇒Ch.11.5.), in order to reduce the stretching of the spring and to prevent unwanted movements of the drive mechanism, which may cause severe injuries.

11.1. Problems and Remedies

Check power supply voltages of the board's fuse. PLA1300 board: OK LED should be steadily lit Variable frequency drive: the green square FREQ should be steadily lit and the green RUN LED should blink.		
SYMPTOM(S)	PROBABLE CAUSE(S)	CHECK(S) OR APPROPRIATE SOLUTION(S)
The barrier remains open	An opening command is sent continuously.	Ensure the opening command is a pulse and not a continuous command.
	The (optional) switch is in "forced opening".	Check condition of the (optional) switch.
	The swing-off sensor does not signal "presence of arm"	Swing-off of the arm is not properly adjusted. The sensor is maladjusted. Check via a shunt on the electronic board to simulate the sensor (refer to the electronic diagram).
	No signal received from the high position sensor. Barrier in calibration with variable frequency drive blocked.	Sensor out of service or maladjusted. <u>Note:</u> <ul style="list-style-type: none"> - Barrier low → High sensor OFF / Low sensor ON - Barrier high → High sensor ON / Low sensor OFF - Barrier in mid-position → High and Low sensors ON.
	Electronic board is faulty.	Check if the OK LED of the PLA1300 is steadily lit. Check the external commands via shunts at the board terminal block.
	Variable frequency drive is faulty.	See chapter on error codes of the frequency converter (⇒Ch.11.2.).
	The (optional) loop detector remains active.	Check the detector's sensitivity and reset the loop detector to zero. If the sensitivity setting is too high, it can cause the barrier to be locked open.
		Check whether the LEDs on the detector are signalling a detector or loop failure.
	The (optional) cell is signalling a presence	Check photocell alignment.
		Ensure photocells are not dirty.
The barrier remains closed.	No opening command is received.	Check if the barrier operates by simulating an opening command.
	The (optional) switch is in "forced closing".	Check condition of the (optional) switch.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

Check power supply voltages of the board's fuse. PLA1300 board: OK LED should be steadily litVariable frequency drive: the green square FREQ should be steadily lit and the green RUN LED should blink.		
SYMPTOM(S)	PROBABLE CAUSE(S)	CHECK(S) OR APPROPRIATE SOLUTION(S)
	Variable frequency drive is faulty.	See chapter on error codes of the frequency converter (⇒Ch.11.2.).
	No signal received from the Low position sensor. Barrier in calibration with variable frequency drive blocked.	Sensor out of service or maladjusted. <u>Recall:</u> - Barrier low → High sensor OFF / Low sensor ON - Barrier high → High sensor ON / Low sensor OFF - Barrier in mid-position → High and Low sensors ON.
	Control logic is faulty.	Check if the OK LED of the PLA1300 is steadily lit. Check the external commands via shunts at the board terminal block.
The barrier takes a long time to close after a vehicle has passed	The closing after passage timer is set for too long	See page <i>General configuration</i> of the maintenance interface (see appropriate manual).
	The opening command is given again during the passage.	Set a lower pulse time for the barrier opening command.
The barrier opens for no apparent reason.	The opening loop (optional) is too sensitive.	Adjust the sensitivity and/or frequency of the opening detector. A sensitivity setting that is too high or an improper frequency may cause unwanted openings.
	The access control system sends unwanted commands.	Check the LEDs of the inputs on the PLA1300 board. Check the access control system.
The arm is incorrectly positioned on the (optional) tip support.	The arm strikes the tip support with too much force.	Adjust the lower stop (⇒Ch.6.2.)
	The arm stops before it reaches the tip support.	Adjust the position sensors. (⇒Ch.11.8.3.)
The arm bounces in the high and/or low position	The adjustable stops inside the barrier are too tight.	Adjust the stops (⇒Ch.6.2.) Reinitialize the barrier via the page <i>Maintenance interface motor tests</i> (see appropriate manual).
The power disconnects when the barrier is turned on	An incorrect differential circuit breaker is being used.	Use a differential circuit breaker as recommended in Ch.0

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

11.2. Adjusting the Variable Frequency Drive

The factory settings protect the variable frequency drive and the gear motor from all malfunctions. The settings of the variable frequency driver should therefore never be modified.



Any modification of these parameters without prior express permission from Automatic Systems is your full responsibility and will automatically void the product warranty.



During normal operation, the DRV LED is lit. The variable frequency drive then displays the operating frequency of the motor.

Main Error Messages

In the event of a fault, in addition to the blinking of the **ALM** LED, the VFD can indicate the origin of the fault via codes. The most common faults are described below.



After switching off the power supply, this code disappears and will no longer be visible when it is switched on again. It is therefore imperative to record this code before reinitializing the barrier.


CODES	DESCRIPTION	
Uu 1	Insufficient supply voltage of the VFD (Uu 2), of faulty motor phase (Uu 2)	
Uu 2		
Ou	Voltage of the SC bus has exceeded its max. limit	
oH (blinking)	VFD temperature rise	
oL1	Motor overload	Check the balancing of the arm and perform operational tests to check if the VFD does not make any noise. The barrier may have been vandalised during closing or opening
oL2	Variable frequency drive overload	
Bb (blinking)	Check the wiring of the variable frequency drive at the inputs	
oC	Short circuit or insulation fault at the VFD output (check motor windings and insulation).	
GF	Ground problem.	

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.


11.3. Opening the Top Cover

- 1) Turn the lock 90° anticlockwise.
- 2) Lift the cover and pull it toward you.



11.4. Switching Equipment Off

- Open the door (→ 11.3.).
- Lower the circuit breaker (14) to deactivate the barrier.



Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

11.5. Manual Raising of Arm

The procedure to be followed for manually raising the arm differs according to the configuration, as shown in the following table:

BARRIER CONFIGURATIONS	PROCEDURE
With automatic raising of the arm in the event of a power cut. (optional)	<ul style="list-style-type: none"> Shut off the power supply (⇒Ch.11.4.) ⇒ the spring (⇒Ch.4.1. , item 9) automatically raises the arm.
Without automatic raising of the arm in the event of a power cut.	<ul style="list-style-type: none"> Shut off the power supply (⇒Ch.11.4.); Operate the manual brake release lever located on the motor (⇒Ch.4.1. , item 15); Manually raise the arm (with sufficient force to overcome the resistance of the brake). Release the brake release lever.

11.6. Replacing the Spring Assembly

Tools required: Ratchet and 16-mm ratchet extension.

- Open the door (⇒Ch.11.3.).
- Shut off the power supply (⇒Ch.11.4.).
- Raise the arm slightly past 90° and tighten the upper stop so that the arm does not fall back down.
- Note down the position of the upper location of the spring (9) on the hub (6) ⇒ Fig. 1.




Fig. 1




Fig. 2




Fig. 3


- Loosen the locknut (9.1) and completely release the spring tension by loosening the nut (9.2) ⇒ Fig. 2.
- Unscrew the screw (80) for retaining the spring assembly on the hub and remove the faulty assembly ⇒ Fig. 3.
- Replace the spring assembly (9) and put the washers (82 & 83) and the fastening screw (80) back into position. Screw down everything.
- Adjust the vertical position of the arm (⇒Ch.11.4.).
- Adjust the spring tension (⇒Ch.6.3.).

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

11.7. Table of Main Spring Adjustments

Position of the spring(s) on the stop hub



Useful length of the arm (in metres)	SR MODEL Without thread		AVR MODEL Without thread		SR MODEL With low thread		AVR MODEL With low thread	
	Nbr of spring(s)	Position(s) on the axle	Nbr of spring(s)	Position(s) on the axle	Nbr of spring(s)	Position(s) on the axle	Nbr of spring(s)	Position(s) on the axle
2	-	-	1	0	-	-	1	1
2.5	-	-	1	1	-	-	1	1
3	-	-	1	1	1	1	1	2
3.5	-	-	1	2	1	2	1	2
4	1	1	1	2	1	3	2	2+2
4.5	1	2	2	1+2	1	3	2	2+3
5	2	0+1	2	2+2	2	2+2	2	3+3
5,5	2	1+1	2	2+3	Not available			
6	2	2+3	2	3+3				

Reading the table:

The yellow boxes indicate the position of the spring on the hub. If only one number appears, only one spring is needed; if two numbers are indicated, two springs must be mounted.



The spring is considered correctly tensioned if it can no longer vibrate with the arm in the high position.

For the high and low threads, contact our Customer Service.

For models equipped with an electromagnet roller, over-dimension the setting to the higher size.


Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

Checking the proper balancing of the arm

- On SR model barriers (without automatic raising), the arm positioned at 45% with the brake disengaged should be lowered slowly.
- On AVR model barriers (with automatic raising), when the arm is in horizontal position, it should be raised gently in the event of a power failure.

In addition to the high location of the spring on the hub, a fine adjustment can be performed by tightening or loosening the nuts H M10 at the bottom of the spring (see picture below).




- First proceed with the loosening of the locknut (9.1.).
- Then proceed with the fine adjustment of the spring tension by tightening (pressing) or loosening (releasing) the nut (9.2).
- Check the proper balancing of the arm in accordance with the instructions given at the start of this chapter.
- Tighten and block the locknut (9.1).

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

11.8. Replacing the Position Sensor

11.8.1. Location of the Position Sensors



By convention, when the user is located in front of the barrier, the inductive sensor located to his left controls the high position.

11.8.2. Operation of the Position Sensors

- Opening or closing sequence: motor start at high speed after an acceleration ramp.
- Passage of the trough of the cam in front of the sensor: activation of low speed and start of the end-of-movement timer.
- Stopping of movement by mechanical contact of the adjustable stop on the frame.
- Disconnection of the motor's electrical power supply upon expiry of the end-of-movement timer.

The inductive sensors are intended to command the VFD to switch to low speed while at the same time initiating a timer that will shut off the motor's electrical power supply.



Never operate the barrier, manually or electrically, without the adjustable stops.

Technical Manual BL227-MT-EN


The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

11.8.3. Adjusting the Sensors

Fine adjustment of the horizontal and vertical positions of the arm requires only an adjustment of the adjustable stops (Ch.4.1. , point 7). If the barrier is out of adjustment following a problem, if there is rebounding or if the operating speed has been modified, the setting of the detection cams should be altered. For this, proceed as follows:

Loosen the locking screw of the relevant cam and slightly rotate the cam. The low speed should be activated as late as possible and be virtually invisible to the eye, so as to keep the operating time as short as possible.

Adjusting the low speed deactivation during rising or descending, according to the selected cam.



11.8.4. Replacing an Inductive Position Sensor



Tools required: Two 17 mm open-ended wrenches – flat screwdriver – cutting pliers – Rilsan collars

- Remove the top cover (⇒Ch.11.3.) and shut off the electrical power supply (⇒Ch.11.4.).
- Loosen and remove the 2 retaining nuts M12 of the faulty inductive sensor.
- Disconnect the sensor wires from the relevant terminal blocks on the electronic board.
- Replace the sensor and reconnect the wires.
- Ensure that the distance between the sensor's detection head and the boss of the cam is between 2 and 3 mm.
- Check the barrier's setting during operation and, if necessary, adjust the cam position (⇒Ch.11.8.3.).

11.9. Replacing the Gear Motor



Tools required: 10 mm and 17 mm tubular wrenches – 13 mm, 16 mm & 17 mm open-ended wrenches - 3 mm, 4 mm & 6 mm Allen wrenches – flat and cross-headed screwdriver – flat file – mallet – bronze drift Ø25 – sandpaper – cutting pliers – drift punch – circlip pliers

- Remove the top cover (⇒Ch.11.3.) and shut off the electrical power supply (⇒Ch.11.4.).
- Remove the arm (barrier in vertical position)
- IF OPTIONAL AVR OR ARM ≥ 4 M : detach the spring from the upper hub (locate the position of the spring shaft on the hub)
- Loosen the 2 screws H M10 to remove the hub
- Disassemble the electronic board + frequency converter sub-assembly
- Loosen the eccentric ring of the bearing using the 4 mm Allen wrench and rotate it by a quarter turn to unlock it
- Detach the sensor support bracket from the gear motor by removing the 2 screws H M8
- Rub the shaft with sandpaper so as to remove the protective varnish
- Open the circlip and the detection cams (locate their positions) and slide them onto the shaft
- File off the marking of the bearing ring locking screw
- Remove the external bearing protection plate by removing the 4 screws CBLH M10
- Take out the shaft by tapping on the bearing side with the bronze drift
- Open the motor terminal box, locate and disconnect the wires and then take out the cables
- Place a support under the gear motor to lift it prior to loosening it
- Loosen the 4 fastening nuts M10 of the flange
- Remove the assembly and proceed with the assembly of the new gear motor
- Reinstall in reverse order and check the proper functioning of the barrier

11.10. Inverting the Sides for Mounting the Arm

Tools required: 10 mm and 17 mm tubular wrenches – 13 mm, 16 mm & 17 mm open-ended wrenches - 3 mm, 4 mm & 6 mm Allen wrenches – flat cross-headed screwdriver – flat file – mallet – bronze drift Ø25 – sandpaper – cutting pliers – drift punch – circlip pliers

- Proceed with the removal of the gear motor assembly (see above).
- Remove the assembly and proceed with its reassembly on the other side of the frame.
- Reinstall in reverse order.
- Modify the position of the inductive position sensors.
- Invert 2 motor phases.

Adjust the position cams (⇒Ch.11.8.3.)

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

12. PROLONGED SHUTDOWN/DESTRUCTION


If the barrier is not to be used for a long period, it is recommended:

- To store the barrier in a dry place away from heat and protected against the weather.
- To leave the power on. If the motor remains permanently powered, a certain temperature is maintained in the body. This eliminates problems of condensation and, at low temperature, prevents the gear motor oil from solidifying, which would have the effect of not reproducing the performance of the barrier during the first switching operations following a long period of inactivity.

When the equipment is taken out of service, drain the oil from the gear motor (⇒ Ch.4.1. , point 5) and scrap the various components of the machine through the appropriate channel (metal parts, electronic components, etc.) according to the legislation in force in the country concerned.

13. TERMINOLOGY

Swing-off When the arm comes out of its jaw, in the case of vehicle impact:



- HMI** (Human Machine Interface)
Switches and LEDs located on the PLA1401 motherboard that interface with the unit.
- Arm** Obstacle to prevent passage that moves up (barrier open) or down (barrier closed).
- Direction A** By convention, the direction A is the passage from free area to controlled area.
- Direction B** By convention, the direction B is the passage from controlled area to free area.
- VF** Variable Frequency Driver.
- N/A** Not Applicable.

14. EC DECLARATION OF CONFORMITY



EC declaration of conformity

We, undersigned,

AUTOMATIC SYSTEMS SAS
22 rue du 8 mai 1945
95340 PERSAN
FRANCE

Herewith declare that the following machine

Electrical rising barrier type

BL 227

is in accordance with the conditions of the following Directives, standards and other specifications:

- Machinery Directive 2006/42/CE.
- Low-voltage Directive 2006/95/CE.
- Electromagnetic compatibility Directive 2004/108/CE.
- RoHS Directive 2011/65/EU.
- EEN 12100-1 (2003): Machinery – Basic terminology and methodology.
- EN 12100-2 (2003): Machinery – Technical principles and specifications.
- EN 60204-1 (2009): Safety of machinery. Electrical equipment of machines. General requirements.
- EN 61000-6-3 (2007): Electromagnetic compatibility (EMC). Generic standards. Emission standard for residential, commercial and light-industrial environments.
- EN 61000-6-2 (2006): Electromagnetic compatibility (EMC). Generic standards. Immunity standard for industrial environments.

Made in PERSAN,
Date: 2015.11.13
Name: Cyrille DELLINO
Function: Vehicle division - Technical Director



Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement. Document subject to change without notice.

15. ANNEXES

Wiring diagram(s): the wiring diagram(s) to be used as reference is(are) the diagram(s) delivered with the equipment. It(they) are included in the equipment.

AUTOMATIC SYSTEMS BELGIUM - HQ

E-mail: asmal@automatic-systems.com

Tel.: +32.10.23 02 11

Fax: +32.10.23 02 02

Belgium

Wallonia-Brussels

Tel: +32 70 22 44 66

Fax: +32 10 86 22 90

Email: helpdesk.be@automatic-systems.com

Canada

Tel: +1 450 659 0737

Fax: +1 450 659 0966

Email: helpdesk.nam@automatic-systems.com

Deutschland

Tel: +49 2303 943295

Email: helpdesk.de@automatic-systems.com

Spain

Tel: +34 93 478 77 55

Fax: +34 93 478 67 02

Email: helpdesk.es@automatic-systems.com

United States

Tel: +1 450 659 0737

Fax: +1 450 659 0966

Email: helpdesk.nam@automatic-systems.com

Belgium

Flanders

Tel: +32 70 22 44 66

Fax: +32 3 88 700 76

Email: dnv.be@automatic-systems.com

China

Tel: +86 512 5383 0561

Email: helpdesk.cn@automatic-systems.com

France

Tel: +33 1 30 28 95 53

Email: helpdesk.fr@automatic-systems.com

United Kingdom

Tel: +44 (0) 1604 654 210

Fax: +44 (0) 1604 654 110

Email: helpdesk.uk@automatic-systems.com



Before contacting us for a technical problem, please note the **serial number** (on the product only) as well as **the model** of your equipment.
This information is needed to properly identify your equipment.

Technical Manual BL227-MT-EN

The information contained in this document is the property of Automatic Systems and is confidential. The recipient shall refrain from using it for any purpose other than the use of the products or the execution of the project to which it refers, and from communicating it to third parties without Automatic Systems' prior written agreement.
Document subject to change without notice.